

PART NUMBER	DESCRIPTION	REF.NO.
213358	JOINT WASHER-EXHAUST PIPE	2C05
213700	DOWEL	1C02
213700	DOWEL	1C11
213700	DOWEL	1E02
213700	DOWEL	1H03
213959	WSHR FOR RADIATOR DRAIN PLUG	2D02
213961	JOINT WASHER	1F03
214058	JOINT WASHER	1D09
214229	GROMMET-RUBBER	1M05
214649	RUBBER COVER	1K06
214649	SEAL-STEERING BALL JOINT	1K07
214649	RUBBER COVER	1K08
214662	RETAINER	1K06
214662	RETAINER-STEERING BALL JOINT	1K07
214662	RETAINER	1K08
214685	SPRING RING	1K06
214685	SPRING-STEERING BALL JOINTS	1K07
214685	SPRING RING	1K08
214795	CIRCLIP	1H04
214795	CIRCLIP	1I06
214965	CIRCLIP	1H09
214995	BUSH OIL PUMP	1C04
214995	BUSH-OIL PUMP GEAR	1D05
214995	BUSH-OIL GEAR PUMP	1E04
215170	BOLT(0.3125" BSF X 1.59375")	1H09
215331	BOLT(0.375" BSF X 1.59375")	1J10
215331	BOLT	1J11
215331	BOLT	1J13
215599	BOLT 0.25 WHIT X 1.25 LONG	1H03
215703	BOLT (0.375" WHIT X 1")	2E08
215808	CLEVIS COMPLETE	1H12
215809	CLEVIS COMPLETE	1L05
216421	PIN-CLEVIS-TRANSMISSION BRAKE	1L05
216421	CLEVIS PIN	1L15
216708	CLIP	1N11
216708	CLIP-PIPE	1N12
216912	NUT	1G04
216914	WASHER	1G05
216962	CIRCLIP	1I11
217268	BEARING FOR SWIVEL PIN	1J06
217325	BEARING-BALL	1H10
217325	BEARING-BALL	1I10
217352	KEY WASHER	1J10
217352	KEY WASHER	1J11
217352	WASHER-LOCK	1J13

PART NUMBER	DESCRIPTION	REF.NO.
217353	LOCKER	1J10
217353	LOCKER	1J11
217353	WASHER-LOCK	1J13
217400	OIL SEAL	1J02
217400	SEAL-OIL	1J03
217445	SPRING	1H13
217476	LOCKER	1H04
217477	NUT	1H04
217478	BEARING	1H09
217484	PLATE	1H07
217490	BEARING	1H07
217523	PLATE	1H09
217525	CIRCLIP	1HC9
217546	CIRCLIP	1H08
217564	BOLT 0.3125 BSF X 1 LONG	1H08
217564	BOLT	1H11
217564	BOLT	1H13
217568	RETAINER	1H08
217620	SHIM	1H09
217622	SHIM	1H09
217694	FLANGE PLATE	1K05
217778	STUD-GEARBOX TRANSFER CASING	1H09
217970	PLATE	1H09
217977	STUD	1H09
217978	STUD	1H09
217978	STUD	1H10
217985	FELT RING	1L14
217985	SEAL-HANDBRAKE CROSS SHAFT	1L15
218243	HIGH GEAR WHEEL	1H07
218244	MAINSHAFT GEAR	1H04
218386	BUSH	1L15
218453	CROSSMEMBER	2G02
218508	STARTING HANDLE	2L11
218983	SPRING,PULL OFF	1L04
218983	BRAKE SHOE RETURN SPRING	1L02
219098	HUB CAP	1J10
219098	HUB CAP	1J11
219098	CAP-HUB	1J13
219521	KNOB	1H13
219676	CLIP-PIPE	1I05
219680	GROMMET	1N17
219680	GROMMET	2L14
219704	TOOL ROLL	2L11
219709	BRACKET	1H13
219714	LEVER HOUSING	1H11

PART NUMBER	DESCRIPTION	REF. NO.
219721	SEAT	1H11
219722	PLATE	1H11
219723	SPRING	1H11
219797	CIRCLIP	1H11
230034	BUSH	1D07
230062	WASHER	1D11
230086	BUSH	1H12
230140	JOINT WASHER	1H09
230250	CORE PLUG	1C11
230250	CORE PLUG	1D11
230250	CUP PLUG	1E11
230251	CORE PLUG	1D11
230279	PIN	1H12
230294	RETAINER FOR SEAL	1K05
230313	KEY	1C05
230313	KEY-WOODRUFF	1D06
230313	KEY-WOODRUFF	1E05
230511	JOINT WASHER FOR DRAIN PLUG	1J06
230696	HOUSING ASSEMBLY	1H09
230736	SPANNER	2L11
230759	SPRING	1K05
230760	WASHER	1K05
230939	LEVER	1009
231033	SCREW-STOP	1H11
231116	SPRING FOR REVERSE STOP	1H11
231190	CHAIN	1N14
231190	CHAIN	1N15
231190	CHAIN	1N16
231190	CHAIN-FUEL FILLER CAP	1N17
231218	COVER	1D03
231219	JOINT WASHER	1D03
231318	PIN	1L14
231341	STUD	1H03
231343	SETSCREW	1D07
231344	SPACER	1D07
231348	ROCKER SHAFT	1D07
231349	ROCKER SHAFT	1D07
231352	WASHER SPRING	1D07
231393	RETURN SPRING-ACCELERATOR	1011
231505	JOINT WASHER FOR HUB	1J10
231505	JOINT WASHER FOR HUB	1J11
231505	GASKET-REAR HUB	1J13
231576	WASHER JOINT	1C13
231576	JOINT WASHER	1D12
231576	WASHER	1N10

PART NUMBER	DESCRIPTION	REF.NO.
231576	JOINT WASHER	2L15
231577	JOINT WASHER	1C11
231577	WASHER JOINT ROCKER SHAFT	1D08
231577	WASHER-OIL PIPE	1D11
231601	WHEEL-ROAD	1J18
232037	SEALING WASHER	1C11
232037	SEALING WASHER	1C12
232037	WASHER JOINT	1D11
232037	JOINT WASHER	1D12
232037	JOINT WASHER	1E12
232038	WASHER-PLAIN	1I03
232038	JOINT WASHER	2G10
232039	JOINT WASHER	1C11
232039	WASHER JOINT	1C12
232039	WASHER-OIL PIPE	1D11
232039	JOINT WASHER	1E11
232039	WASHER JOINTT	1E12
232039	JOINT WASHER	1E12
232040	WASHER JOINT	1D08
232041	JOINT WASHER	1D13
232042	JOINT WASHER	1E07
232042	JOINT WASHER	1E08
232043	JOINT WASHER	1E07
232043	JOINT WASHER	1E08
232043	JOINT WASHER	1F06
232043	SEALING WASHER	1F07
232044	WASHER	1C04
232044	WASHER JOINT	1C14
232044	JOINT WASHER	1E04
232044	WASHER-SEALING-CARBURETTER-	2L12
232074	SPRING POST	1L04
232074	SPRING POST	1L02
232413	JOINT WASHER FOR HOUSING	1J05
232415	OIL THROWER	1H04
232464	PIN	1H12
232497	STUD	1H09
232538	BOLT	2G04
232565	RETAINING PLATE	1H08
232566	RETAINING PLATE	2F08
232590	BULB	2F08
232608	PLATE	1H11
232813	KNOB	1H12
232846	THRUST BUTTON-SPEEDO CABLE	1H09
233220	JOINT-WASHER	1G04
233220	JOINT WASHER	1G05

PART NUMBER	DESCRIPTION	REF.NO.
233220	GASKET-MASTER CYLINDER	1L12
233220	WASHER	1L09
233241	LOCKING DOG	1H10
233243	RUBBER GROMMET	2F06
233243	GROMMET-RUBBER-BLACK	2L09
233244	GROMMET-RUBBER-BLACK	2L09
233246	GROMMET	1I13
233326	SPRING-CHAIN TENSIONER	1C04
233326	SPRING-TIMING CHAIN TENSION	1E05
233328	CIRCLIP	1C04
233328	RETAINER	1E05
233398	SHAFT	1H13
233406	SELECTOR SHAFT BLOCK	1H12
233406	BLOCK-TRANSFER SHAFT	1H13
233407	COUPLING	1H12
233409	SHOULDERED PIN	1H12
233409	PIN	1H13
233416	SHAFT	1H12
233419	'O'RING-VALVE	1D07
233419	RUBBER RING	1D11
233437	BUSH	1H13
233438	TUBE	1H13
233441	PLUG	1H13
233449	SPRING	1H12
233520	BANJO BOLT	1D11
233770	CLIP	2L08
234124	BUSH-TIMING PINION	1C04
234124	BUSH-TIMING CHAIN WHEEL	1E05
234532	NIPPLE	1J02
234532	NIPPLE-GREASE	1J03
234532	NIPPLE GREASE	1J14
234603	BOLT (2 BA X 0.50")	1L07
234603	BOLT (2 BA X 0.50")	1L07
234603	BOLT	1L09
234603	BOLT	1L10
234603	BOLT	1L11
234603	BOLT	1L12
234603	BOLT	1L13
234603	BOLT	1N13
234603	BOLT	1N13
234603	BOLT	2F10
234603	BOLT	2G08
234603	BOLT	2G09
234603	SCREW	2L14
234658	COLLAR	1H12

PART NUMBER	DESCRIPTION	REF.NO.
234889	SPRING	1L03
235113	GROMMET-(BREATHER TO	1J02
235113	GROMMET-(BREATHER TO	1J03
235113	GROMMET	2F04
235416	PLUNGER	1H13
235455	SHIM	1H09
235592	PLUG	1H09
235592	PLUG-OIL DRAIN-AXLE	1J02
235592	PLUG-AXLE-DRAIN	1J03
235592	PLUG-OIL DRAIN-AXLE	1J12
235592	PLUG-DRAIN-FUEL TANK	1002
235592	PLUG-FUEL TANK DRAIN	1004
235770	KEY	1C03
235770	KEY WOOD RUFF	1E03
235968	RETAINER FOR OIL SEAL	1J05
236022	JOINT WASHER	1C11
236022	WASHER-THERMOSTAT SWITCH	1D11
236022	GASKET-OIL TEMP SWITCH	1F06
236067	IDLER WHEEL	1C04
236067	WHEEL-TIMING CHAIN	1E05
236070	DRAIN PLUG	1J06
236072	MUDSHIELD-DIFFERENTIAL HSG	1J07
236074	MUDSHIELD	1H08
236074	EXCLUDER-MUD	1H10
236257	DOWEL	1D05
236257	DOWEL	1E04
236305	SEAL	1H04
236357	DOWEL	1C04
236365	CLIP	2L08
236366	CLIP	2F04
236366	CLIP-DOUBLE	2L08
236407	UNION NUT	1D08
236408	OLIVE	1D08
236541	RETAINER	1H10
236548	MUDSHIELD	1H10
236630	FLANGE	1H08
236632	MUDSHIELD	1J07
236658	PEDAL SHAFT	1007
236658	SHAFT-ACCELERATOR PEDAL	1011
236665	ACCELERATOR SHAFT BRACKET	1007
236891	BOWL	1N06
236993	ANCHOR	1L04
236993	ANCHOR FOR BRAKE SHOE	1L02
236995	LOCKING PLATE	1L04
236995	LOCKING PLATE	1L02

PART NUMBER	DESCRIPTION	REF.NO.
236998	ACCELERATOR SHAFT BRACKET	1007
236998	BRACKET-ACCELERATOR SHAFT	1011
237100	CHECK STRAP	2G02
237119	SET BOLT (2 BA X 0.375")	1C11
237121	BOLT 2BA X 0.625 LONG	1N11
237121	BOLT	1N12
237121	BOLT	1N13
237121	BOLT	1N13
237251	STUD	1H09
237324	BOLT(0.3125" BSF X 0.875")	1G02
237339	BOLT(0.375" BSF X 1")	1J08
237339	BOLT	1L02
237339	BOLT	1L03
237357	SET BOLT(0.4375" BSF X 1.375")	1J06
238180	RELAY LEVER ASSY	1L15
238329	LINK	1H13
238542	SPECIAL SCREW	1L04
238542	SPECIAL SCREW	1L02
238793	BEARING	1010
238871	RETAINING PLATE	1D07
239449	BRACKET	1D03
239600	CLIP-LH ADAPTOR	1M11
239600	CLIP	2L12
239600	CLIP	2L08
239673	CLIP	1014
239688	LEAD	2F10
239688	LEAD-EARTH-WIPER MOTOR	2F11
239710	PLATE-EXHAUST MTG TO PIPE	2C04
239710	PLATE-EXHAUST MOUNTING TO PIPE	2C05
239710	PLATE-EXHAUST MOUNTING TO PIPE	2C07
239710	PLATE-EXHAUST MOUNTING TO PIPE	2C08
239710	PLATE-EXHAUST MOUNTING TO PIPE	2C10
239711	CLIP-EXHAUST MOUNTING	2C03
239711	CLIP-EXHAUST MOUNTING	2C04
239711	CLIP-EXHAUST MOUNTING	2C05
239712	CLAMP	2C06
239715	RETAINER-EXHAUST MOUNTING	2C03
239715	RETAINER-EXHAUST MOUNTING	2C04
239715	CLAMP PLATE	2C05
239715	RETAINER-EXHAUST MOUNTING	2C06
239715	RETAINER-EXHAUST MOUNTING	2C07
239715	RETAINER-EXHAUST MOUNTING	2C08
239715	RETAINER-EXHAUST-MOUNTING	2C10
239715	CLAMP PLATE	2C11
239716	BRACKET	2C06

PART NUMBER	DESCRIPTION	REF. NO.
240087	CLIP-EXHAUST MOUNTING	2C06
240407	CLIP-PIPE	1H09
240407	CLIP	2L08
240417	CLIP	2L08
240428	CABLE CLIP	1M08
240429	CLEAT	1013
240429	CLEAT-(BREATHER TO BRAKE PIPE)	1J12
240429	CABLE CLIP	1M08
240429	CLIP-FIRTREE	2F06
240429	CLIP-FIRTREE	2F12
240429	CLEAT	2F15
240429	CLIP-FIRTREE	2L08
240429	CLIP-FIRTREE	2L13
240429	CLEAT-EARTH LEAD TO WATER	2L17
240429	CLEAT FIXING PIPES	2L17
240431	CLEAT	1N05
240431	CLIP-FIRTREE	2L08
240555	DRIVERGEAR-OIL PUMP	1C04
240555	GEAR-OIL PUMP	1D05
240555	GEAR-OIL PUMP	1E04
240708	RETAINER-CLUTCH SPRING	1G04
240708	PLATE-ANCHOR-BRAKE SPRING	2L12
240708	ANCHOR FOR SPRING	1L15
240836	SCREW DRIVER	2L11
241283	ROAD SPRING	1J15
241380	BUMP RUBBER	2G02
241388	THRUST WASHER	1K05
241598	PLATE	1H11
241839	LOCKER	1H09
242127	U BOLT	1J17
242139	RING,LIFTING AND TOWING	2G04
242139	TOWING RING	2G12
242520	STUB SHAFT	1J05
242522	CIRCLIP	1J02
242522	CIRCLIP	1J03
242522	CIRCLIP	1J04
242522	CIRCLIP	1J05
242522	CIRCLIP	1J14
242863	ROAD SPRING	1J15
243022	WASHER-PLAIN	1J16
243095	GREASE CAP	2E07
243095	CAP-STARTER MOTOR END	2E08
243121	MAIN LEAF FRONT SPRING	1J15
243121	LEAF-MAIN-ROAD SPRING	1J16
243123	MAIN LEAF	1J17

PART NUMBER	DESCRIPTION	REF.NO.
243124	2ND LEAF	1J17
243126	2ND LEAF	1J15
243126	LEAF--2ND--ROAD SPRING	1J16
243130	DOWEL	1J17
243131	DOWEL	1J15
243296	WHEEL CYLINDER	1L02
243296	CYLINDER RH WHEEL-REAR BRAKE	1L04
243297	WHEEL CYLINDER	1L02
243297	CYLINDER LH WHEEL-REAR BRAKE	1L04
243302	WHEEL CYLINDER	1L02
243303	WHEEL CYLINDER	1L02
243395	CLIP	1L11
243395	CLIP	1L13
243395	CLIP	1N13
243395	CLIP	1N13
243395	CLIP	2L12
243611	SHAFT	1H10
243618	STUD	2K06
243714	SPRING	1H13
243743	WHEEL CYLINDER	1L03
243744	WHEEL CYLINDER	1L03
243873	OIL THROWER	1H10
243958	JOINT WASHER	1C02
243958	WASHER JOINT	1C08
243958	WASHER JOINT	1C09
243958	WASHER	1C13
243958	WASHER JOINT	1D11
243958	JOINT WASHER	1E02
243958	JOINT WASHER	1F05
243958	WASHER-PLAIN	1L07
243958	JOINT WASHER-DRAIN PLUG	1002
243958	JOINT WASHER-DRAIN PLUG-FUEL TANK	1003
243958	JOINT WASHER-FUEL TANK DRAIN PLUG	1004
243958	JOINT WASHER-DRAIN PLUG-TANK	1006
243959	JOINT WASHER	1C02
243959	WASHER-OIL DRAIN PLUG	1C07
243959	JOINT WASHER	1C10
243959	JOINT WASHER	1C11
243959	WASHER JOINT	1D07
243959	WASHER JOINT	1D08
243959	JOINT WASHER	1E02
243959	JOINT WASHER	1E07
243959	JOINT WASHER	1E08
243959	JOINT WASHER	1E10
243959	JOINT WASHER	1E11

PART NUMBER	DESCRIPTION	REF.NO.
243967	JOINT WASHER	1F05
243968	JOINT WASHER	1C02
243968	JOINT WASHER	1E02
243968	JOINT WASHER	1F05
243969	JOINT WASHER	1D10
243970	WASHER	1D03
243971	JOINT WASHER	1D05
243972	WASHER JOINT	1D11
243972	JOINT WASHER	1E11
244009	DISTANCE PIECE-EXHAUST MOUNTING	2C03
244009	DISTANCE PIECE-EXHAUST MTG	2C04
244009	DISTANCE PIECE	2C05
244009	DISTANCE PIECE-EXHAUST MOUNTING	2C06
244009	DISTANCE PIECE-EXHAUST MOUNTING	2C07
244009	DISTANCE PIECE-EXHAUST MOUNTING	2C08
244009	DISTANCE PIECE-EXHAUST MOUNTING	2C10
244009	DISTANCE PIECE	2C11
244150	BEARING FOR HALFSHAFT	1J05
244151	DISTANCE PIECE FOR BEARING	1J05
244162	PLATE	1J17
244384	HANDLE-STARTING	2L11
244449	INTERMEDIATE EX PIPE	2C03
244487	LOCKWASHER	1C04
244487	WASHER-LOCK	1E04
244488	SEALING RING	1C04
244488	'O'RING-OIL PUMP STRAINER	1E04
244706	BRACKET	2E07
244706	BRACKET-END-STARTER MOTOR	2E08
244711	PINION & SLEEVE	2E07
244711	PINION-STARTER MOTOR	2E08
244713	BRACKET FOR STARTER MOTOR	2E07
244714	BUSH	2E07
244714	BUSH-STARTER MOTOR PINION	2E08
244718	SUNDRY PARTS KIT	2E07
244718	KIT-SUNDRY PARTS-STARTER	2E08
245003	CLAMPING PLATE	2E03
245014	DOG-DISTRIBUTOR DRIVING	2E04
245599	ATTACHMENT PLATE	2L02
245857	RETAINING PLATE-DISTRIBUTOR	2E04
245857	RETAINER PLATE DISTRIBUTOR	2E05
245926	RETAINER-EXHAUST MOUNTING	2C06
245926	RETAINER-EXHAUST MOUNTING	2C07
245926	RETAINER-EXHAUST MOUNTING	2C10
245926	PACKING PIECE	2C11
245940	PLUNGER	1D05

PART NUMBER	DESCRIPTION	REF.NO.
246109	TOWING HOOK	2L02
246169	SEAL RING	1G02
246169	'O'RING-FLYWHEEL HOUSING	1G03
246464	DOWEL	1C03
246464	DOWEL	1D04
246464	DOWEL	1E03
246565	ANCHOR PLATE	1L03
246566	ANCHOR PLATE	1L03
247040	SPRING	1C06
247040	SPRING-LOCKERS	1E06
247051	BOLT (0.50" UNF X 4.5625")	1C11
247051	BOLT-SPECIAL	1E11
247070	JOINT WASHER FOR COVER	1C05
247070	JOINT WASHER-CAMSHAFT COVER	1E05
247078	SPECIAL SET BOLT	1C10
247078	BOLT	1D09
247078	BOLT-SPECIAL	1E09
247121	SPECIAL NUT	1C11
247121	SPECIAL NUT	1C12
247121	DOME NUT	1E12
247127	PLUG	1C02
247127	SCREW-SPECIAL	1E02
247135	BOLT(0.4375" UNF X 0.875")	1G02
247135	BOLT	1G03
247143	STUD	1E11
247144	STUD	1C04
247144	STUD	1C11
247144	STUD	1E05
247144	STUD	1E11
247145	STUD	1G02
247145	STUD	1G03
247146	STUD	1G03
247153	WASHER	1E06
247179	JOINT WASHER	1N10
247199	SPECIAL BOLT	1C04
247199	BOLT-SPECIAL	1E05
247212	JOINT WASHER-DISTRIBUTOR PUMP	1N10
247212	JOINT WASHER	2E02
247212	WASHER JOINT	2E03
247554	JOINT WASHER	1E09
247554	JOINT WASHER	1C08
247555	JOINT WASHER	1E09
247555	JOINT WASHER	1C08
247583	BUSH	1E03
247606	ROCKER COVER GASKET	1E12

PART NUMBER	DESCRIPTION	REF.NO.
247607	STUD FOR ROCKER SHAFT	1E06
247614	BUSH VALVE ROCKER	1C06
247624	COVER-RUBBER WASHER	1C11
247624	COVER FOR RUBBER WASHER	1C12
247631	ENGINE BREATHER FILTER	1C11
247634	TAPPET CLEARANCE PLATE	1C11
247634	TAPPET CLEARANCE PLATE	1C12
247634	PLATE-VALVE CLEARANCE	1E12
247653	BUSH	1E04
247665	LOCKWASHER	1C04
247665	WASHER-LOCK	1E04
247683	BOLT	1E11
247709	CAMSHAFT	1C05
247723	BOLT	1E11
247726	NOZZLE	1N10
247737	BUSH	1E06
247738	BUSH	1E06
247742	CIRCLIP	1C04
247742	CIRCLIP	1E04
247755	SET BOLT(0.5625" UNF X 3.25")	1C02
247755	SET BOLT	1E02
247766	MUD EXCLUDER	1C07
247766	EXCLUDER-MUD	1E08
247766	DEFLECTOR-FRONT COVER	1F04
247802	JOINT WASHER	1N10
247824	JOINT WASHER	1C13
247861	PLUG	1C02
247861	SCREW-SPECIAL	1E02
247874	JOINT WASHER	1C10
247874	GASKET-THERMOSTAT HOUSING	1E10
247912	PISTON ASSEMBLY-TIMING CHAIN	1C04
247912	PISTON CHAIN ADJUSTER	1E05
247952	LEAD	1E11
247953	LEAD	1E11
247965	PLUG	1C02
247965	DOWEL	1E02
248720	BOLT(0.50" BSF X 2")	1H02
250053	WING NUT 0.375 UNF	2H02
250053	WING NUT	2H05
250053	WING NUT	2H12
250431	WING NUT	2G04
250543	BOLT	2E08
250544	BOLT(0.375" BSF 1.75")	1H09
250551	BOLT(0.375" BSF X 3.50")	1J15
250551	BOLT	1J16

PART NUMBER	DESCRIPTION	REF.NO.
250551	BOLT	1J17
250551	BOLT	1J18
250693	BOLT(0.25" BSF X 0.625")	1J05
250830	CORE PLUG	1E11
250962	BOLT (2BA X 0.875")	1014
251002	SET BOLT (2BA X 0.4375")	1C11
251002	BOLT	1D11
251018	BOLT (2BA X 0.5625")	1H10
251018	BOLT	2L12
251321	SELF LOCKING NUT(0.3125 BSF)	1H03
251322	NUT-SELF LOCKING	1C14
251322	NUT-SELF LOCKING	1D15
251322	NUT(0.375 BSF)	1J05
251322	NUT-SELF-LOCKING	1L02
251322	NUT	1L04
251323	NUT(0.4375" BSF)	1J15
251323	NUT-SELF LOCKING	1J17
251324	NUT(0.50" BSF)	1H02
251335	NUT (2BA)	1H10
251335	NUT	2L12
251601	NUT(0.3125" BSF)	1H12
251601	NUT-CASTLE	1H13
252163	SELF LOCKING NUT 0.4375 UNF	1D11
252163	NUT	1J16
252165	NUT(0.5625" UNF)	1J15
252165	NUT-SELF LOCKING	1J16
252165	NUT-SELF LOCKING	1J16
252165	NUT-SELF LOCKING	1J17
252165	NUT-SELF LOCKING	1J18
252165	NUT-SELF LOCKING	1J18
252180	WING NUT	2G04
252211	NUT	1G04
252496	STUD	1D12
252501	STUD	1D11
252513	STUD	1F02
252514	STUD	1C08
252514	STUD	1C09
252514	STUD	1F06
252514	STUD	1M04
252515	STUD	1D11
252516	STUD	1F10
252516	STUD	1F11
252516	STUD	2E16
252621	STUD	1C02
252621	STUD	1D03

PART NUMBER	DESCRIPTION	REF.NO.
252621	STUD	1E02
252621	STUD	1E13
252622	STUD	1D03
252623	STUD	1F08
252626	STUD	1D03
252626	STUD MANIFOLD AND EXHAUST	2L17
252627	STUD	1D03
253003	SET BOLT	1D11
253028	BOLT 0.3125 UNC X 1 LONG	1G05
253067	BOLT	1F02
253205	BOLT	1D14
253205	BOLT	1010
253205	BOLT (0.250"UNC X 0.562")	2E02
253205	BOLT	2E03
253205	BOLT	2E04
253205	BOLT	2E05
253205	BOLT(0.25"UNC X 0.5625"LONG)	2L17
253206	SET BOLT	1C08
253206	BOLT	1F04
253206	BOLT	1F06
253206	BOLT	1F11
253206	BOLT	1M09
253826	BOLT	1J16
253830	BOLT	1J17
253905	BOLT (0.375" UNF X 0.625")	1E11
253960	BOLT 0.312"UNF X 2.375 LONG	2E13
254810	NUT	1G04
254824	NUT	1J16
254824	NUT	1J18
254831	NUT	1G05
254862	NUT	1G05
254862	NUT(0.375" UNF)	1H13
255029	BOLT	1G04
255202	BOLT	1F02
255202	BOLT	1G04
255202	BOLT(0.25" UNF X 0.375")	1L06
255204	BOLT	1D06
255204	BOLT	1E05
255204	BOLT	1007
255204	BOLT	1009
255204	BOLT	1011
255204	BOLT	2C09
255204	BOLT	2G08
255204	BOLT	2K06
255205	BOLT(0.25" UNF X 0.5625")	1N13

PART NUMBER	DESCRIPTION	REF. NO.
255205	BOLT(0.25" UNF X 0.5625")	1N13
255205	BOLT	2C09
255205	BOLT	2K02
255205	BOLT	2K03
255206	BOLT	1D03
255206	BOLT	1D06
255206	BOLT	1K05
255206	BOLT	1L07
255206	BOLT	1M04
255206	BOLT	1N07
255206	BOLT	1N08
255206	BOLT	1N09
255206	BOLT	1N11
255206	BOLT	1N12
255206	BOLT	1N13
255206	BOLT	1N13
255206	BOLT	1007
255206	BOLT	1009
255206	BOLT	1010
255206	BOLT	1011
255206	BOLT	2C09
255206	BOLT	2D02
255206	BOLT	2G02
255206	BOLT	2G04
255206	BOLT	2G06
255206	BOLT	2G07
255206	BOLT	2G08
255206	BOLT	2G10
255206	BOLT	2G12
255206	BOLT	2G13
255206	BOLT	2G15
255206	BOLT	2H02
255206	BOLT	2H03
255206	BOLT	2H04
255206	BOLT	2H05
255206	BOLT	2H06
255206	BOLT	2H07
255206	BOLT	2H08
255206	SCREW	2H14
255206	BOLT	2H15
255206	BOLT	2H18
255206	BOLT	2K02
255206	BOLT	2K04
255206	BOLT	2K05
255206	BOLT	2K06

PART NUMBER	DESCRIPTION	REF. NO.
255206	BOLT	2L15
255207	BOLT	1C08
255207	BOLT (0.25" UNF X 0.75")	1C10
255207	BOLT	1E09
255207	BOLT	1N09
255207	BOLT	1007
255207	BOLT	1011
255207	BOLT	2F09
255207	BOLT	2F12
255207	BOLT	2G02
255207	BOLT	2G06
255207	BOLT	2G07
255207	BOLT	2G13
255207	BOLT	2G15
255207	BOLT	2G16
255207	BOLT	2G18
255207	BOLT	2H02
255207	BOLT	2H04
255207	BOLT	2H08
255207	BOLT	2H15
255207	BOLT	2H17
255207	BOLT	2H18
255207	BOLT	2J09
255207	BOLT	2J16
255208	BOLT	1D10
255208	BOLT	1N07
255209	BOLT	1G04
255211	BOLT (0.250" UNF X 1.250")	1009
255227	BOLT	1D05
255227	BOLT	1D08
255227	BOLT	1G04
255227	BOLT	1K04
255227	BOLT	1L15
255227	BOLT	1007
255227	BOLT	1009
255227	BOLT	1011
255227	BOLT	2E02
255227	BOLT	2E13
255227	BOLT	2G02
255227	BOLT	2G17
255227	BOLT	2H02
255227	BOLT	2H07
255227	BOLT	2H16
255227	SCREW	2I02
255227	BOLT	2I15

PART NUMBER	DESCRIPTION	REF.NO.
255227	BOLT	2L12
255227	BOLT	2L12
255229	BOLT (0.3125" UNF X 1.125")	2G18
255229	BOLT	2H15
255230	BOLT 0.3125 UNF X 1.25 LONG	2H07
255245	BOLT	1005
255245	BOLT (0.375"UNF X 0.750")	2C09
255245	BOLT	2C09
255248	BOLT(0.375" UNF X 1.125")	1G02
255249	BOLT(0.375" UNF X 1.25")	1L14
255249	BOLT	2I02
255427	BOLT	1G03
256001	BOLT	1D11
256040	BOLT(0.375" UNF X 1.375")	1G02
256041	BOLT(0.375" UNF X 1.50")	1G02
256093	BOLT 0.50 UNF X 4.50 LONG	1J18
256208	BOLT(0.25"UNF X 2.25")	1D10
256220	BOLT	2G05
256220	BOLT	2H08
256220	BOLT	2I15
256222	BOLT	1G05
256233	BOLT(0.3125" UNF X 3.75")	1C07
256233	BOLT	1C10
256295	BOLT 0.50 UNF X 5" LONG	1J16
257004	BOLT	1E09
257011	NUT	1M12
257015	BOLT 10 UNF X 0.375"	1M07
257015	BOLT	2D04
257015	BOLT	2F09
257015	BOLT	2J06
257015	BOLT	2L15
257015	SCREW(NO.10 ϕ UNF X 0.375LONG)	2L17
257017	BOLT	1N17
257017	BOLT (10 UNF X 0.500")	2C09
257017	SCREW	2F13
257017	SCREW	2F14
257017	SCREW	2F15
257017	SCREW	2L15
257019	BOLT	1014
257019	BOLT 10 UNF X 0.625 LONG	2F12
257020	BOLT	1M12
257020	SCREW NO 10 X 0.750 LONG	2J03
257064	BOLT	1F06
257123	BOLT	1M12
257302	BOLT 10 UNF X 2.125"	2F04

PART NUMBER	DESCRIPTION	REF. NO.
260055	STARTER BRUSHES	2E07
260055	BRUSH-STARTER MOTOR	2E08
261414	SEAL	1N02
261414	GASKET-AIR CLEANER	1N02
261414	GASKET-AIR CLEANER	1N03
261850	BUSH FOR ROCKER SHAFT	1K02
261857	JOINT WASHER	1K02
261869	ROLLER FOR MAIN NUT	1K02
261873	ADJUSTER SCREW	1K02
261874	LOCKNUT	1K02
262703	BUSH AND SPRING	2E02
262703	BRUSH AND SPRING DISTRIBUTOR	2E04
262703	BRUSH/SPRING DISTRIBUTOR CAP	2E05
262703	BRUSH AND SPRING FOR CAP	2L17
262704	ROTOR ARM	2E04
263524	GROMMET	2K14
264024	WASHER-PLAIN	1J16
264024	WASHER-PLAIN	1J17
264195	INTERMEDIATE EX PIPE	2C03
264362	SPRING	2I02
264563	SPRING	1J15
264569	GUDGEON PIN	1D04
264590	BULB	2F03
264590	BULB	2F03
264591	BULB	2F04
264591	BULB	2F05
264591	BULB	2F06
264767	SEALING WASHER	1G04
264782	BULB HOLDER	2F03
264782	CONNECTOR-STOP TAIL LAMP	2F03
264886	BRACKET-EXHAUST MTG TO PIPE	2C04
264889	CLAMP	2C04
265038	BANJO BOLT	1D11
265169	GUDGEON PIN	1C03
265175	CIRCLIP	1C03
265295	ROOF LAMP	2F06
265295	ROOF LAMP	2J06
265295	ROOF LAMP	2J07
265461	DOWEL	1J15
265461	SCREW-ROAD SPRING	1J16
265482	LEAD-ROOF LAMP	2F06
265482	LEAD ROOF LAMP	2J06
265482	LEAD ROOF LAMP	2J07
265601	FLEXIBLE MOUNTING	2C05
265627	SPRING	1J15

PART NUMBER	DESCRIPTION	REF.NO.
265627	SPRING-ROAD-PASSENGER'S	1J16
265779	DOWEL	1C03
265779	DOWEL	1E03
266034	CLAMP PLATE EXHAUST MOUNTING	2C05
266035	DISTANCE PIECE EXHAUST MOUNTING	2C05
266036	DISTANCE PIECE EXHAUST MOUNTING	2C05
266321	VALVE SEAT INSERT	1D11
266662	CAMSHAFT CHAIN	1D06
266684	OVERHAUL KIT-FRONT	2L07
266684	WHEEL CYLINDER KIT	1L03
266687	OVERHAUL KIT-REAR	2L07
266687	WHEEL CYLINDER KIT	1L02
266900	OIL STRAINER	1D05
266945	CIRCLIP	1E03
266956	DUST COVER	1H10
266992	SEAL	1H12
267412	ANCHOR FOR SPRING	1L15
267451	SPRING-CHAIN ADJUSTER	1C04
267451	SPRING-TIMING CHAIN TENSIONER	1E05
267572	THRUST WASHER	1H04
267573	THRUST WASHER	1H04
267574	THRUST WASHER	1H04
267575	THRUST WASHER	1H04
267604	JOINT-WASHER	1F06
267668	GASKET	1D12
267782	JOINT WASHER	1H08
267828	SEALING WASHER	1D08
267828	WASHER-SEALING	1H08
267829	DRIVE SHAFT	1D05
267837	JOINT WASHER	1002
267837	JOINT WASHER-FUEL TANK OUTPUT PIPE	1004
268292	VALVE SPRING CAP	1C06
268292	RETAINER-VALVE COLLET	1D07
268292	RETAINER VALVE SPRING	1E06
268292	CAP-VALVE SPRING	2L12
268293	SPLIT CONE FOR VALVE HALVES	1C06
268293	COLLET-VALVE	1D07
268293	COLLET VALVE	1E06
268293	COTTER HALVES-VALVE SPRINGS	2L12
268791	SLEEVE	1H08
268847	LEVER	1H12
268849	HOUSING	1H10
268883	CLIP	2K14
268887	O RING	1C08
268887	FILTER SEALING RING	1C11

PART NUMBER	DESCRIPTION	REF.NO.
268887	O RING	1D12
268887	SEAL-ENGINE BREATHER	1E12
269132	STOP CLIP	1007
269132	CLIP-ACCELERATOR LEVER SHAFT	1011
269132	CLIP-RETAINING ACCELERATOR	1014
269257	GROMMET FOR SERVO PIPES	2L09
269265	HALFSHAFT COMPLETE FOR	1J05
269266	HALFSHAFT COMPLETE FOR	1J05
269783	BUSH-CLUTCH PEDAL	1G04
269783	DISTANCE PIECE	1L06
269889	RUBBER WASHER	1C12
269889	WASHER	1E12
269889	WASHER-OIL FILTER BOLT	1E12
270225	WASHER-SPRING	2E09
270225	BRUSH SET STARTER MOTOR	2E09
270520	PLATE	1J15
270656	TUBE OF SILICONE GREASE 10Z	1C03
270656	GREASE SILICONE	1D04
270656	GREASE SILICONE	1E03
271013	'O' RING FOR STEERING BOX	1K02
271014	PLAIN WASHER-STEERING BOX	1K02
271379	JOINT WASHER	1K02
271384	ADJUSTABLE RACE	1K02
271386	PLUG	1K02
271872	ELBOW	1002
271881	PEG	1E11
272185	BRACKET	1H09
272451	GALLERY PIPE	1D03
272452	WATER PIPE	1D03
272498	ENGINE MOUNTING	1C14
272498	BRACKET-ENGINE MOUNTING	1D15
272498	BRACKET-ENGINE MOUNTING REAR cLH	1E13
272501	ENGINE MOUNTING	1C14
272501	BRACKET-ENGINE MOUNTING	1D15
272501	BRACKET-ENGINE MOUNTING REAR cRH	1E13
272506	ENGINE MOUNTING	1C14
272506	BRACKET-ENGINE MOUNTING FRONT	1E13
272512	GROMMET-(BREATHER PIPE)	1J12
272512	GROMMET	1N08
272512	GROMMET-FUEL PIPE	1N13
272512	GROMMET-FUEL PIPE	1N13
272539	GASKET-OIL FILTER	1C12
272539	GASKET-OIL FILTER	1E12
272539	O RING	1E12
272596	SEAL	1H11

PART NUMBER	DESCRIPTION	REF. NO.
272597	SEAL	1H11
272632	PEDAL BRACKET	1G04
272712	SPINDLE	1G04
272712	SHAFT PEDAL	1L06
272713	COVER-PEDAL BRACKET	1G04
272713	PEDAL BRACKET COVER	1L06
272713	COVER-TOP PEDAL BRACKET	2L12
272714	BUSH-CLUTCH PEDAL	1G04
272714	BUSH FOR PEDAL	1L06
272749	BOLT	1D03
272804	BRACKET	1013
272804	BRACKET PEDAL SHAFT	1007
272804	BRACKET-ACCELERATOR SHAFT	1009
272804	BRACKET-ACCELERATOR SHAFT	1011
272819	GASKET-PEDAL BRACKET COVER	1G04
272819	GASKET	1L06
272819	GASKET-UPPER BRACKET TOP	2L12
272835	JOINT WASHER	1D09
272922	LOCKER	1J08
272934	BOLT	1J08
273069	SEALING WASHER	1C06
273069	WASHER	1C11
273069	WASHER	1C12
273069	WASHER-SPECIAL	1E06
273069	WASHER-PLAIN	1E12
273069	JOINT WASHER	1N10
273163	BUSH	1D04
273166	PLUG	1C02
273166	PLUG	1E02
273306	ROCKER SHAFT	1D08
273307	ROCKER SHAFT	1D08
273308	SPACING WASHER	1D08
273309	SHIM FOR VALVE ROCKER	1D08
273370	GROMMET-LH ADAPTOR	1M11
273370	GROMMET	1N12
273441	DIFFERENTIAL CASING ASSEMBLY	1J08
273521	BANJO BOLT	1N10
273711	PLUNGER	1C04
273711	PLUNGER OIL RELIEVE VALVE	1E04
273964	BALL END	1010
274084	HOUSING ASSEMBLY	1D05
274086	SPECIAL SCREW	1D05
274089	NUT	1D12
274091	NUT	1D08
274093	BOLT(0.375"UNF X 0.90625")	1D12

PART NUMBER	DESCRIPTION	REF. NO.
274100	PLATE	1D12
274104	JOINT WASHER	1D13
274115	BEARING	1D06
274116	BEARING	1D06
274117	BEARING	1D06
274118	SPECIAL SCREW	1D06
274173	WASHER JOINT	1C11
274173	JOINT WSHR FOR ROCKER COVER	1C12
274423	BRAKE DRUM	1L05
274469	CHECK STRAP	2G02
274609	JOINT WASHER	1D13
274711	CAMSHAFT	1E05
274737	DIST PIECE FOR FAN BLADES	1D10
274772	ROCKER	1E06
274773	ROCKER	1E06
274774	ROCKER	1E06
274775	ROCKER	1E06
274817	WASHER JOINT	1D08
274870	RETAINER-EXHAUST MOUNTING	2C04
274870	RETAINER-EXHAUST MOUNTING	2C06
274870	RETAINER-EXHAUST MOUNTING	2C07
274870	PACKING PIECE	2C11
274928	OIL FEED BOLT	1D05
275199	CLEVIS FORK END	1L15
275234	DAMPER-TIMING CHAIN	1D06
275234	DAMPER-TIMING CHAIN	1E05
275265	JOINT WASHER	1N10
275266	BANJO BOLT	1N10
275324	VIBRATION DAMPER	1C04
275565	JOINT WASHER	1N06
275565	GASKET-FUEL PUMP	1N10
275679	PIPE	1C11
275679	PIPE-ENGINE OIL	1E11
275744	KIT-WHEEL CYLINDER OVERHAUL	1L04
275744	OVERHAUL KIT-FRONT	2L07
275744	WHEEL CYL KIT	1L02
275836	OIL PIPE	1D03
276034	SPRING	1J15
276034	SPRING-ROAD-DRIVER'S	1J16
276054	GROMMET	2L09
276133	CHAINWHEEL	1E05
276141	INTERMEDIATE EXHAUST PIPE	2C04
276322	PLUG SPANNER	2L11
276323	PLUG SPANNER EXTENSION	2L11
276396	SPANNER	2L11

PART NUMBER	DESCRIPTION	REF.NO.
276397	SPANNER	2L11
276482	CASTLE NUT(0.4375 UNF)	1K06
276482	NUT-CASTELLED	1K07
276484	RUBBER GROMMET	1J02
276510	JOINT WASHER	1D11
276511	BRACKET	1G02
276511	BRACKET-FLYWHEEL PLUG	1G03
276541	SEALING RING	1D06
276719	HALFSHAFT ONLY RH	1J05
276720	HALFSHAFT LH	1J05
276784	STEERING TUBE	1K06
276784	TUBE-LONGTITUDINAL-	1K07
277103	HOUSING FOR ACCELERATOR	1007
277103	BRKT-ACCELERATOR PDAL SHAFT	1011
277120	BUSH	1008
277153	PEDAL SHAFT	1007
277153	SHAFT-ACCELERATOR PEDAL	1009
277153	SHAFT-ACCELERATOR PEDAL	1011
277217	SPANNER	2L11
277259	FILLER TUBE COMPLETE	1N14
277259	FILLER TUBE COMPLETE	1N15
277259	FILLER TUBE COMPLETE	1N16
277260	CAP FOR FUEL FILLER	1N14
277260	CAP FOR FUEL FILLER	1N15
277260	CAP FOR FUEL FILLER	1N16
277261	TUBE	1N14
277261	TUBE	1N15
277261	TUBE	1N16
277262	TUBE	1N14
277262	TUBE	1N15
277262	TUBE	1N16
277289	GASKET FOR SWIVEL PIN HOUSING	1J06
277311	LOCKER-BRAKE BACKPLATE	1L02
277311	LOCKER-BRAKE BACKPLATE	1L03
277320	SPANNER	2L11
277388	CYLINDER-CHAIN ADJUSTER	1C04
277388	CYLINDER-TIMING CHAIN	1E05
277453	BUSH	1012
277454	PIN-BELL CRANK	1012
277455	RETURN SPRING	1007
277455	SPRING-ACCELERATOR RETURN	1010
277455	SPRING-ACCELERATOR PEDAL	1011
277473	LEVER-ACCELERATOR SHAFT	1011
277475	ACCELERATOR LEVER	1007
277475	LEVER-ACCELERATOR LINKAGE	1010

PART NUMBER	DESCRIPTION	REF. NO.
277475	LEVER-ACCELERATOR	1011
277502	SPRING	1013
277502	SPRING	1012
277532	STUD	1G03
277565	ANCHOR	1012
277778	NUT	1012
277840	SUPPORT BRACKET RESERVOIR TANK	1G04
277956	DOWEL	1C06
277956	DOWEL	1E06
278010	CLIP PIPE	1F06
278109	IDLER GEAR-OIL PUMP	1C04
278109	GEAR-OIL PUMP	1D05
278109	GEAR-OIL PUMP	1E04
278161	LINER	1C13
278162	PACKING	1M04
278163	WASHER JOINT	1C08
278163	WASHER JOINT	1C09
278163	JOINT WASHER	1M04
278164	PLUG	1D11
279413	PLUG	1D03
279415	PLUG	1D03
279648	SPECIAL SET BOLT	1C11
279652	AIR CLEANER	1N02
279652	AIR CLEANER	1N03
279653	HOSE CLIP	1N02
279678	SPRING	1J17
279679	SPRING	1J17
279970	PLATE	1J17
300816	GRAB HANDLE	2G02
300824	BONNET REST STRIP 35" LONG	2G05
301005	HOOK	2K07
301321	RING FOR EYELET	2H16
301321	RING-EYELET	2I02
301347	RUBBER PLUG	2K04
301347	RUBBER PLUG	2K05
301437	SEAL	2G10
301437	GROMMET	2G11
301470	REAR SEAT BACK REST PANEL	2K07
301476	RETAINING ROD FOR REAR SEAT	2K07
301879	RIVET	2H02
301879	RIVET	2H04
301879	RIVET	2H07
302177	WEATHER STRIP	2H17
302178	FILLER STRIP	2H17
302186	POP RIVET	2J13

PART NUMBER	DESCRIPTION	REF. NO.
302222	RIVET	2G13
302222	RIVET	2G17
302371	RUBBER WASHER	2H17
302373	RUBBER WASHER	2H17
302533	BOLT	2G10
302533	BOLT	2G17
302648	STRAP	2K07
302818	RIVET	2H18
302825	BRACKET	2H03
302825	RETAINER-TAILBOARD CHAIN	2H06
302828	CLEVIS PIN	2H03
302828	CLEVIS-TAILBOARD CHAIN	2H06
302933	TIE BAR	2H02
302933	PIVOT-SPARE WHEEL MOUNTING	2H05
302933	STUD	2H12
302934	WING NUT	2H02
302934	WING-NUT	2H05
302934	WING NUT	2H12
303750	SPECIAL BOLT	2G08
303750	BOLT-SPECIAL	2G10
303817	RETAINER	2G10
303817	RETAINER	2G11
303828	COVER PLATE	2G10
303847	CLAMP	2H02
303847	RETAINER-SPARE WHEEL MOUNTING	2H05
303847	CLAMP SPARE WHEEL	2H12
303875	HINGE COMPLETE	2H05
303875	HINGE-LOCKER LID	2H07
303975	SEALING RUBBER	2H13
304054	PAD	2K06
304125	BUFFER	2I02
304125	BUFFER-RUBBER-SEAT SQUAB	2J09
304125	BUFFER-RUBBER-SEAT SQUAB	2J11
304125	BUFFER-RUBBER-SEAT SQUAB	2J13
304301	BRACKET	2L04
304401	LID FOR LOCKER	2H05
304401	LID-LOCKER	2H07
304716	RETAINER	2J04
305192	POP RIVET	2H15
305232	PLATE PACKING-DOOR CHECK	2G18
305232	SHIM FOR CAB BODY	2H02
305232	PLATE-BODY PANEL FRONT	2H04
305232	PLATE-STIFFENER-REAR BODY	2H07
305232	BRACKET-TOE PANEL	2H08
305232	PLATE-DOOR STRIKER	2H18

PART NUMBER	DESCRIPTION	REF.NO.
306287	WEATHER STRIP-SIDE LIGHT	2H16
306289	FILLER STRIP-SIDE LIGHT	2H16
306295	BUFFER	2G18
306295	BUFFER-RUBBER-REAR DOOR	2H16
306295	BUFFER	2I02
306316	BOARD-BASE-REAR SEAT	2K04
306316	SEAT BASE PANEL	2K06
306407	NAME PLATE	2H03
306407	BADGE 'STATION WAGON'	2H07
306460	DOOR PULL HANDLE	2J08
306564	CLEVIS PIN	2G16
307220	RUBBER PLUG	2G09
307220	PLUG-RUBBER	2L08
307418	FINISHER-FRONT REAR SEAT	2K04
307418	FINISHER-FRONT-REAR SEAT	2K05
307418	FINISHER	2K06
307419	FINISHER-RH-SIDE REAR SEAT	2K04
307419	FINISHER-RH-REAR SEAT	2K05
307419	FINISHER	2K06
307420	FINSIHER-LH-SIDE-REAR SEAT	2K04
307420	FINISHER-LH-REAR SEAT	2K05
307420	FINISHER	2K06
307840	RIVET	2I02
308206	TREAD PLATE	2H05
308517	TUBULAR RIVET	2G17
308517	RIVET	2H17
308517	RIVET	2H18
310877	RUBBER BUFFER FOR FRONT	2G05
311373	SHAKEPROOF WASHER	2F09
312027	BUFFER	2I02
312028	RUBBER BUFFER	2K06
312856	GROMMET-(CHASSIS SIDEMEMBER)	1J12
312856	GROMMET	2F06
313385	NUT	1N14
313385	NUT	1N16
313385	NUT	1N17
315264	CLIP-TRIM	2K02
315264	CLIP-TRIM	2K03
315960	CLIP	2K02
315960	CLIP	2K03
315960	CLIP-SEAT COVER RETAINING	2K04
320045	BLT MUSH HEAD 0.25 X0.75cLONG	2G10
320045	SCREW	2G11
320045	SCREW	2H04
320045	SCREW	2H07

PART NUMBER	DESCRIPTION	REF.NO.
320521	REAR SEAT HINGED BASE	2K07
320604	TAILBOARD	2H13
320608	LENS FOR ROOF LAMP	2F06
320609	BARREL LOCK	2H18
320674	CUSHION	2K07
320679	TRIM CASING	2J08
320682	CASING	2J07
320682	CASING RH-SIDE LIGHT	2J08
320683	CASING	2J07
320683	CASING LH-SIDE LIGHT	2J08
320684	CASING	2J07
320684	CASING RH-SIDE LIGHT	2J08
320685	CASING	2J07
320685	CASING LH-SIDE LIGHT	2J08
320686	CANT RAIL	2J07
320686	TRIM RH-CANTRAIL	2J08
320687	CANT RAIL	2J07
320687	TRIM LH-CANTRAIL	2J08
320698	SEAT SQUAB	2J09
320698	SEAT SQUAB	2J11
320699	SEAT CUSHION	2J10
320699	SEAT CUSHION	2J11
320701	SEAT SQUAB	2J09
320701	SEAT SQUAB	2J11
320702	SEAT SQUAB	2J09
320702	SEAT SQUAB	2J11
320703	SEAT BACKREST	2K06
320708	SEAT SQUAB	2J09
320709	SEAT SQUAB	2J09
320710	SEAT SQUAB	2J09
320711	CANT RAIL	2J07
320712	CANT RAIL	2J07
320715	DOOR CASING	2J08
320716	DOOR CASING	2J08
320719	REAR SEAT SQUAB	2K08
320726	CUSHION	2J09
320861	REAR BODY COMPLETE 109 2.25	2H04
320863	REAR BODY LOWER ASSEMBLY 88	2H02
320901	STG BALL JOINT RH THREAD	1K06
320902	BALL JOINT ASSY LH THREAD	1K06
320902	BALL JOINT	1K07
320903	STEERING TRACK ROD ASSEMBLY	1K06
330037	FRONT FLOOR PLATE RH	2G10
330038	FRONT FLOOR PLATE LH	2G10
330069	GEARBOX DIAPHRAGM	2G10

PART NUMBER	DESCRIPTION	REF. NO.
330122	TOP CAPPING	2G13
330123	TOP CAPPING	2G13
330144	COVER PLATE	2G08
330145	BODY CAPPING	2H06
330146	SUPPORT BRACKET	2G15
330162	BUFFER	2G14
330162	FILLER-GLASS REAR SIDE DOOR	2G17
330163	SEALING STRIP SIDESCREEN-DOOR	2G14
330198	RETAINER	2G14
330202	FILLER	2G14
330203	FILLER	2G14
330203	FILLER-GLASS-REAR SIDE DOOR	2G17
330208	BRACKET	2H02
330212	RUBBER STRIP	2H02
330214	REAR BODYSIDE ASSY RH 88	2H02
330215	REAR BODYSIDE ASSY LH 88	2H02
330237	CORNER BRACKET	2H03
330237	BRACKET RH-TAILBOARD RETAINER	2H06
330237	BRACKET-CORNER TAILBOARD RH	2H08
330238	CORNER BRACKET	2H03
330238	BRACKET LH-TAILBOARD RETAINER	2H06
330238	FRACKET-CORNER TAILBOARD LH	2H08
330245	CAPPING FRONT PANEL	2H03
330245	CAPPING-BODY FRONT	2H06
330265	CROSS MEMBER	2H02
330265	STIFFENER-REAR BODY FLOOR	2H04
330265	CROSSMEMBER-REAR BODY	2H07
330267	REAR FLOOR	2H02
330271	REAR MOUNTING ANGLE	2H02
330303	STAY	2G13
330304	STAY	2G13
330315	HOOD SOCKET	2H03
330315	CAPPING RH-BODY CORNER REAR	2H06
330316	HOOD SOCKET	2H03
330316	CAPPING LH-REAR CORNER	2H06
330348	RETAINER	2G12
330349	COVER PLATE	2G12
330366	COWL	2H02
330366	PANEL-FUEL FILLER	2H05
330367	COVER PLATE	2H02
330380	SILL CHANNEL	2G13
330381	SILL CHANNEL	2G13
330422	SLEEVE FOR CHAIN	2H03
330422	COVER-TAILBOARD CHAIN	2H06
330426	OUTER PANEL	2G07

PART NUMBER	DESCRIPTION	REF.NO.
330427	OUTER PANEL	2G07
330443	BOTTOM PANEL-FRT.WING VALANCE	2G08
330459	COVER BOX	2G08
330460	COVER BOX	2G08
330468	MOUNTING ANGLE	2H04
330534	PANEL	2G08
330602	WHEEL HOUSING	2H05
330615	TREAD PLATE FOR REAR BODY	2H05
330616	COVER PLATE	2H05
330617	REAR FLOOR	2H04
330660	SEALING RUBBER	2G14
330660	CHANNEL-REAR SIDE GLASS	2G17
330661	CHANNEL	2G14
330661	FILLER-REAR SIDE GLASS	2G17
330661	CHANNEL-SIDE WINDOW GLASS	2H16
330667	RETAINER	2G10
330668	RETAINER	2G10
330669	RETAINER	2G10
330717	TREAD PLATE VERTICAL FRONT PANEL	2H05
330788	SEAL RETAINER RH	2H17
330789	SEAL RETAINER LH	2H17
330832	CAPPING BODY SIDE	2H03
330833	CAPPING BODY SIDE	2H03
330848	RUNNER	2H16
331006	SEAT SUPPORT	2J09
331006	SEAT SUPPORT	2J11
331007	SEAT SUPPORT	2J09
331007	SEAT SUPPORT	2J11
331007	SEAT SUPPORT	2J13
331008	SEAT SUPPORT	2J09
331008	SEAT SUPPORT	2J11
331008	SEAT SUPPORT	2J13
331083	GROMMET PLUG	2J10
331083	GROMMET PLUG	2J11
331122	PIVOT BRACKET	2K06
331196	SIDE RAIL	2J06
331203	STRIP	2J06
331203	STRIP	2J07
331216	SIDE RAIL	2J07
331229	SEAT FRAME	2K07
331273	STRAP	2J09
331273	STRAP	2J11
331273	STRAP	2J13
331390	OUTER BRACKET	2J06
331391	CENTRE BRACKET	2J06

PART NUMBER	DESCRIPTION	REF.NO.
331391	CENTRE BRACKET	2J07
331401	RUBBER MAT	2J08
331457	FLOOR COVERING	2J04
331466	ADJUSTABLE SEAT FRAME ASSEMBLY	2J10
331466	ADJUSTABLE SEAT FRAME ASSEMBLY	2J11
331478	SUPPORT	2K06
331479	SUPPORT	2K06
331480	RETAINER	2J08
331481	MAT	2J08
331491	ROOF TRIM	2J06
331491	ROOF TRIM	2J07
331508	HEAD CLOTH	2J06
331527	FLOOR COVERING	2J04
331547	STRIP	2J07
331605	HEADCLOTH	2J07
331607	PANEL	2J06
331607	PANEL	2J07
331610	HEADCLOTH	2J07
331616	COVER	2K03
331669	RETAINER	2J08
331670	MAT	2J08
331670	MAT-RUBBER-REAR FLOOR	2K08
331699	BUFFER	2K07
331708	BOLT(0.312" UNF)	2K02
331709	BOLT	2J09
331709	BOLT	2J11
331709	BOLT	2J13
331709	BOLT SPECIAL	2K04
331709	BOLT-SPECIAL	2K05
331818	BRACKET	2J09
331818	BRACKET	2J11
331835	PAD	2K07
331973	STRAP	2J12
331973	STRAP	2J09
331974	STRAP	2J12
331974	STRAP	2J13
331974	STRAP	2J09
332028	LONG STIFFENER CENTRE & OUTER	2H17
332065	STUD PLATE	2H15
332146	BUFFER	2H03
332146	BUFFER-RUBBER-TAILBOARD	2H06
332147	DOVETAIL FOR DOOR PILLAR	2H18
332194	TROPICAL ROOF	2H17
332201	BRACKET	2H15
332215	SEAL	2H15

PART NUMBER	DESCRIPTION	REF.NO.
332216	PACKING STRIP	2H16
332230	RETAINER	2H16
332240	RETAINER	2H17
332280	RETAINER	2H16
332281	RETAINER	2H16
332282	RETAINER	2H16
332283	RETAINER	2H16
332284	RETAINER	2H16
332293	SPECIAL WASHER	2H15
332324	CATCH	2H16
332325	CATCH	2H16
332329	TAPPED PLATE	2H16
332355	STRAP	2J09
332376	BRACKET	2K03
332376	BRACKET	2K04
332400	WASHER PLATE	2G06
332401	BONNET CONTROL	2G06
332435	WINDOW CATCH	2G17
332445	HOOK	2H13
332446	HOOK	2H13
332451	NUT PLATE	2H02
332451	RETAINER-BODY	2H04
332451	RETAINER-REAR BODY	2H07
332484	SUPPORT BRACKET	2G15
332485	SUPPORT BRACKET	2G15
332521	STAY	2H02
332521	BRACKET-REAR BODY WHEELARCH	2H04
332521	BRACKET-REAR BODY STIFFENER	2H07
332563	SEAL LH-REAR DOOR SIDE	2H18
332564	RUBBER SEAL	2H18
332565	PROTECTION STRIP	2H03
332565	PROTECTION STRIP-REAR DOOR	2H18
332566	SEAL RETAINER	2H18
332581	STAY	2G08
332582	PAD	2H02
332582	PAD-MOUNTING BODY	2H04
332582	PAD-MOUNTING BODY	2H07
332647	BUFFER	2G09
332670	NAMEPLATE	2H03
332670	BADGE "LAND ROVER"	2H06
332670	BADGE 'LAND ROVER'	2H07
332672	RUBBING STRIP BRACKET ASSY	2H05
332674	RUBBING STRIP-SPARE WHEEL	2H05
332677	RUBBING STRIP BRACKET	2H12
332733	RETAINER	2G18

PART NUMBER	DESCRIPTION	REF.NO.
332756	RETAINER	2H18
332942	MALE DOVETAIL-DOOR PILLAR	2H18
332943	SPACER	2H18
332983	REAR BODY ASSEMBLY	2H07
333032	RETAINER BOTTOM-REAR DOOR GLASS	2H18
333033	RETAINER	2G17
333033	RETAINER-REAR DOOR GLASS	2H18
333034	RETAINER-TOP-REAR DOOR GLASS	2H18
333035	RETAINER-CORNER-REAR DOOR GLASS	2H18
333036	HINGE	2H16
333036	HINGE	2I02
333041	ROD	2G18
333041	CHECKSTRAP-REAR DOOR	2H16
333041	CHECK STRAP	2I02
333081	FILLER	2G17
333082	PACKING STRIP	2G17
333140	STRIKING PLATE	2G15
333140	STRIKER PLATE	2G18
333140	STRIKER PLATE-REAR DOOR LOCK	2H18
333201	COVER PLATE	2H07
333202	COVER PLATE	2H07
333203	STRIP	2H18
333204	ROD	2G18
333229	SEALING RUBBER	2G17
333233	SEALING RUBBER	2G17
333243	FRONT EXTENSION	2H07
333244	FRONT EXTENSION	2H07
333246	TROPICAL ROOF	2H17
333252	STIFFENER	2H17
333253	PROTECTION ANGLE	2H03
333253	CAPPING RH-REAR BODY SIDE	2H06
333253	CAPPING-BODY END RH	2H08
333254	PROTECTION ANGLE	2H03
333254	CAPPING-LH BODY CORNER REAR	2H06
333254	CAPPING-BODY END LH	2H08
333259	BRACKET FOR SILL REAR END RH	2G17
333260	BRACKET FOR SILL REAR END LH	2G17
333261	SEALING RUBBER	2G17
333262	SEALING RUBBER	2G17
333263	SEALING RUBBER	2H07
333266	CORNER CAPPING	2H08
333267	CORNER CAPPING	2H08
333293	CLIP	2K07
333294	CLIP	2K07
333295	BRACKET	2K07

PART NUMBER	DESCRIPTION	REF. NO.
333395	GRAB RAIL	2K03
333395	GRAB RAIL-SHAPED	2K04
333439	RETAINING PLATE	2H16
333439	RETAINING PLATE	2I02
333445	BUFFER	2H16
333445	BUFFER	2I02
333446	CLAMP PLATE	2H16
333446	CLAMP PLATE	2I02
333452	SIDE AND WHEELARCH	2H07
333487	SEALING RUBBER	2H15
333551	RETAINING SEAT FRAME	2K08
333560	REAR FLOOR	2H07
333562	SIDE AND WHEELARCH	2H07
333693	PANEL	2G12
333714	NUT PLATE	2H08
333719	WAIST MOULDING	2G17
333720	WAIST MOULDING	2G17
333745	SEALING RUBBER	2H07
333835	FRONT VENTILATOR	2H17
333836	REAR VENTILATOR	2H17
333882	GEARBOX COVER	2G10
334111	MOUNTING PAD	2F06
334111	PAD-ROOF LAMP	2J06
334111	PAD-ROOF LAMP	2J07
334121	HINGE PIN	2G09
334174	SQUAB LOCKING PLATE ASSY	2K02
334174	SQUAB LOCKING PLATE ASSY	2K03
334176	BOLT 0.312 UNF	2K02
334176	BOLT 0.312 UNF	2K03
334177	NUT PLATE	2K02
334177	NUT PLATE	2K03
334189	GROMMET	2G10
334391	LOWER PLATE	2K08
334523	HASP	2G12
334523	HASP-LOCKER LID	2H05
334523	HASP-LOCKER LID	2H07
334525	TURNBUCKLE	2G12
334525	TURNBUCKLE-LOCKER LID	2H05
334525	TURNBUCKLE-LOCKER LID	2H07
334532	SEAT BACKREST PANEL	2K08
334540	RETAINING ROD	2K08
334541	FRAME REAR SEAT	2K08
334542	FRAME REAR SEAT	2K08
334573	BRACKET	2K04
334573	BRACKET	2K05

PART NUMBER	DESCRIPTION	REF. NO.
334574	BRACKET-RH	2K05
334574	BRACKET RH	2K04
334575	BRACKET LH	2K04
334575	BRACKET LH	2K05
334601	RETAINING BRACKET	2K08
334612	SEALING RUBBER RH	2H15
334613	SEALING RUBBER LH	2H15
334615	SEALING RUBBER	2H17
334845	RETAINER REAR MAT	2K08
334966	PANEL	2G12
336285	GRAB RAIL ASSEMBLY	2K04
336285	GRAB RAIL ASSEMBLY	2K05
336288	SEAT LOCKING CATCH	2K05
336288	SEAT LOCKING CATCH	2K04
336294	STRIKER PLATE-SEAT LOCK	2K05
336294	STRIKER PLATE SEAT LOCK	2K04
336412	LOCKING PLATE	2H13
336422	COVER	2G10
336451	CHANNEL	2G14
336454	CHANNEL	2G14
336454	CHANNEL-GLASS-REAR SIDE DOOR	2G17
336454	CHANNEL-SIDE WINDOW GLASS	2H16
336503	DISTANCE PIECE FIXING TROPICAL ROOF	2H17
336535	PIVOT PIN	2G06
336536	WASHER	2G06
336738	TIE BOLT	2G09
336764	DRAIN CHANNEL	2H15
336780	RETAINING REAR MAT	2K08
336781	RETAINER REAR MAT	2K08
336782	BOLT PLATE ASSEMBLY	2H04
336872	BRACKET	2G04
336890	DOOR PANEL ASSEMBLY(ALL)	2H18
337290	SEALING RUBBER	2H03
337290	SEAL-RUBBER-TAILBOARD	2H06
337644	WINDSCREEN GLASS	2G10
337710	SILL PANEL	2G13
337711	SILL PANEL	2G13
337771	STAY FOR BODY PANEL AND SILL	2G13
337772	STAY FOR BODY PANEL AND SILL	2G13
337774	BRACKET	2G13
337801	DOOR LOCK	2G15
337801	LOCK-REAR DOOR	2H18
337802	DOOR LOCK	2G15
337806	STUD PLATE	2G15
337806	STUD-PLATE-DOOR LOCK	2G18

PART NUMBER	DESCRIPTION	REF. NO.
337806	STUD PLATE-REAR DOOR LOCK	2H18
337859	FOAM INTERIOR	2J12
337859	FOAM INTERIOR	2J09
337873	FOAM INTERIOR	2J09
337873	FOAM INTERIOR	2J11
337880	FOAM INTERIOR	2J09
337880	FOAM INTERIOR	2J11
337899	FOAM INTERIOR	2J10
337899	FOAM INTERIOR	2J11
337899	FOAM INTERIOR	2J12
337899	FOAM INTERIOR	2J09
337938	SILL PANEL	2G13
337939	SILL PANEL	2G13
337942	SILL PANEL	2G13
337943	SILL PANEL	2G13
338013	SMALL PLUG	2L09
338014	RUBBER PLUG	2F07
338014	PLUG	2F08
338014	PLUG-PLASTIC	2L09
338015	BLANKING PLUG	2F13
338015	PLUG-RUBBER-FRONT WING	2G07
338015	GROMMET	2I03
338015	PLUG-PLASTIC	2L09
338015	PLUG-BLANKING	2L13
338017	BLANKING PLUG	2F13
338018	PLUG FOR 6 WAY SWITCH BRKT	2L09
338020	PLASTIC PLUG	2L09
338021	PLAS PLUG-RED HOLES 0.812 ϕ DIA	2L09
338023	PLASTIC PLUG FOR 1 DIA HOLE	2L09
338026	PLUG-TRANSFER LEVEL HOLE	2G11
338027	PLASTIC PLUG	1L06
338027	PLUG-PLASTIC	2H05
338027	PLUG-PLASTIC	2L09
338027	PLUG-SELF-SEALING	2L13
338029	PLUG	1L06
338029	PLUG-PLASTIC	2L09
338029	PLUG-SELF-SEALING	2L13
338240	TURRET NUT	2G10
338275	SUPPORT BRKT-INTRIOR MIRROR	2I03
338334	GRAB RAIL	2K02
338334	GRAB RAIL	2K03
338345	SUPPORT	2K03
338345	SUPPORT	2K04
338352	SEAT CUSHION INTERIOR	2K03
338353	TRIM BOARD	2K02

PART NUMBER	DESCRIPTION	REF. NO.
338380	SPRING CLIP FIXING STRIP	2G05
338550	RUBBER BUFFER	2H15
338552	BRACKET	2H15
338553	RUBBER BUFFER	2H15
338554	BRACKET	2H15
338617	TAILBOARD HINGE	2H13
338618	TAILBOARD HINGE	2H13
338740	STUD	2H15
338741	STUD	2H15
338743	STRIP	2H03
338780	GROMMET	2G12
338871	SEAL	2G10
338871	SEAL	2G11
339878	RETAINING STRAP ASSEMBLY	2K06
339986	PACKING PIECE	2J13
340391	WASHER	2H16
345100	BRACKET-RH-RETAINING SAFETY	2J16
345100	SILL GUSSET BRACKET RH	2I15
345101	BRACKET-LH-RETAINING SAFETY	2J16
345101	SILL GUSSET BRACKET LH	2I15
345116	RETAINER	2K03
345120	INTERMEDIATE FLOOR	2H07
345140	GROMMET	2G11
345192	SECURING BRACKET FOR PANEL	2G05
345213	WASHER	2J13
345433	DOOR LOCK AND MOUNTING ASSY-ϕRH	2G15
345434	DOOR LOCK AND MOUNTING ASSY-ϕLH	2G15
345435	LOCKING CATCH RH	2G15
345435	CATCH RH-SLIDING WINDOW	2G18
345436	LOCKING CATCH LH	2G15
345436	CATCH LH-SLIDING WINDOW	2G18
345585	INTERIOR DRIVING MIRROR	2I03
345597	MTG BLOCK FOR NUMBER PLATE LAMP	2F04
345620	HEADLAMP MOUNTING PANEL RH	2G07
345621	HEADLAMP MOUNTING PANEL LH	2G07
345623	FRONT PANEL	2G07
345624	FRONT PANEL	2G07
345658	CAPPING	2H15
345659	CAPPING	2H15
345662	CLIP	2F15
345845	DASH VENTILATOR LID RH	2G09
345846	DASH VENTILATOR LID LH	2G09
345915	REINFORCING PANEL FOR TAILBOARD	2H13
346140	CATCH-FEMALE	2H13
346241	NUT PLATE	2G15

PART NUMBER	DESCRIPTION	REF. NO.
346241	RETAINER-STRIKER PLATE	2G18
346341	DOOR HINGE	2H16
346341	DOOR HINGE	2I02
346346	DELUXE GRILLE	2G05
346410	TUBE TRIM RETAINER	2J09
346410	TUBE TRIM RETAINER	2J11
346426	PLUG	2G13
346426	PLUG-REAR SIDE GLASS	2G17
346435	REAR LOWER VALANCE ASSY-LH	2G07
346436	REAR LOWER VALANCE ASSY-LH	2G07
346460	PACKING STRIP BOTTOM	2G14
346461	PACKING STRIP BOTTOM	2G17
346570	GEARBOX DIAPHRAGM PANEL	2G11
346576	VENTILATOR MECHANISM ASSY	2G09
346598	COVER PLATE	2G09
346599	COVER PLATE	2G09
346629	CLOSING PANEL HEATER DUCT-CLH STG	2J03
346675	END CLOSING TRIM RHS	2J02
346676	END CLOSING TRIM LHS	2J02
346679	END CLOSING TRIM	2J02
346680	END CLOSING TRIM	2J02
346702	W/SCREEN COMP LAMINATED SUNDYM	2G10
346713	BRACKET STEERING COLUMN	1K03
346715	CLIP STEERING COLUMN SUPPORT	1K03
346722	BRACKET STEERING COLUMN	1K03
346723	PADDED ASSY HEATER DUCT-CLH ST	2J03
346724	PADDED ASSY HEATER DUCHT-CLH STG	2J03
346749	BLANKING PLATE FOR DASH	2G09
346750	UPPER DASH CRASH PADDING ASSEMBLY	2J02
346760	HEATER SWITCH LABEL	2F07
346761	WIPER WASHER COMBINED LABEL	2F07
346762	SIDE TAIL HEADLAMP LABEL	2F07
346763	INSTRUMENT PANEL ILLUMINATION LABEL	2F07
346765	INSTRUMENT PANEL ILLUMINATION LABEL	2F07
346766	WINDSCREEN WIPER LABEL	2F07
346767	BLANKING PLUG REDUNDANT HOLE	2F07
346786	INSTRUMENT COVER	2J03
346804	CLAMPING BAR	2K06
346813	CLOSING PANEL HEATER DUCT CLH STG	2J03
346817	BLANKING PLATE	2G09
346840	COVER FOR WIPER MOTOR	2J03
346849	BUSH FOR BONNET HINGE	2G06
346853	BONNET HINGE RH	2G06
346854	BONNET HINGE LH	2G06
346857	COVER PLATE HAND CONTROL	1014

PART NUMBER	DESCRIPTION	REF. NO.
346878	CHECK STRAP RETAINING BKT	2G16
346893	DEMISTER OUTLET FRESH AIR GRILLE	2J02
346899	GROMMET INSTRUMENT PANEL CLOSING	2J02
346927	SLIDE RETAINER RH	2G16
346928	SLIDE RETAINER LH	2G16
346941	AIR FLOW DIVIDER PANEL	2G09
346944	COWL FOR INSTRUMENT PANEL	2F07
346945	INSTRUMENT PANEL RHD	2F07
346946	INSTRUMENT PANEL LHD	2F07
346947	PANEL PLUG-HEATER SWITCH HOLE	2F07
346948	PANEL PLUG-INSTRUMENT PANEL	2F07
346981	COVER PLATE	2G09
346984	HINGE ARM TO WINDSCREEN	2G10
346989	HINGE BOLT WINDSCREEN TO DASH	2G10
347018	SILL PANEL RH REAR	2G13
347019	SILL PANEL LH REAR	2G13
347035	BODY SIDE LOWER ASSEMBLY	2H04
347036	BODYSIDE LOWER ASSY LH 109	2H04
347042	REAR BODYSIDE RH 2 6 109	2H04
347043	BODYSIDE LOWER ASSY RH	2H04
347056	REAR BODYSIDE RH 2.25 109	2H04
347057	REAR BODYSIDE LH 109	2H04
347200	SEAT BASE ASSEMBLY	2G12
347308	EDGING STRIP	2F13
347308	EDGING STRIP	2L13
347321	COVER FOR WIPER MOTOR	2J03
347322	WINDOW CATCH COMPLETE	2G15
347322	CATCH-WINDOW	2G17
347343	SEAT FRAME ASSEMBLY CENTRE	2K04
347344	SEAT FRAME ASSEMBLY OUTER	2K04
347344	SEAT FRAME ASSY OUTER	2K05
347362	DOOR HINGE ASSEMBLY RH	2G16
347362	HINGE-RH-REAR SIDE DOOR	2G18
347363	DOOR HINGE ASSEMBLY LH	2G16
347363	HINGE-LH-REAR SIDE DOOR	2G18
347369	SEATING WASHER-DOOR HINGE	2G16
347369	SEATING WASHER-HINGES	2G18
347436	BRACKET	2G13
347441	BOLT PLATE SPARE WHEEL CARRIER	2H16
347441	BOLT PLATE	2I02
347452	BASE STIFFENER-INSTRUMENT PANEL COWL	2F07
347453	BASE STIFFENER-INSTRUMENT PANEL COWL	2F07
347464	NUT PLATE ASSEMBLY	2H05
347474	OUTER PANEL-FRT WING ASSY-RH	2G07
347475	OUTER PANEL-FRT WING ASSY-LH	2G07

PART NUMBER	DESCRIPTION	REF. NO.
347488	WINDOW LIGHT CHANNEL BOTTOM	2G14
347489	WINDOW LIGHT CHANNEL BOTTOM	2G17
347522	EDGE TRIM RH STG	2J03
347523	EDGE TRIM RH LH STG	2J03
347526	SEAL FOR WINDOW CATCH	2G15
347526	SEAL-WINDOW CATCH TO SIDE SCREEN	2G17
347541	CLIP SAFETY HARNESS	2J16
347541	STOWAGE HOOK FOR SEAT BELT	2I15
347553	BRACKET FOR SQUAB BUFFER	2H05
347553	BRACKET SQUAB BUFFER	2J13
347557	SHROUD FOR UPPER STEERING COLUMN	1014
347558	SHROUD FOR UPPER STEERING COLUMN	1014
347567	PROTECTIVE FINISHER FOR ROOF VENT	2H17
347578	ROD FOR CHECK STRAP	2G16
347594	SHIM	2G15
347594	SHIM-STRIKER PLATE	2G18
347637	RETAINER RH	2G10
347638	RETAINER LH	2G10
347646	SHROUD SUPPORT BRACKET RHD	1014
347647	SHROUD SUPPORT BRACKET LHD	1014
347668	CLIP DELUXE GRILLE TO GRILLE	2G05
347698	COVER FOR WIPER MOTOR	2J03
347807	TOE PANEL AND GUSSET BRACKET	2H08
347808	GUSSET BRACKET ASSEMBLY	2H08
347810	BACKING ANGLE	2H08
347861	SQUAB CATCH	2K05
347862	SQUAB CATCH	2K05
347863	NUTPLATE	2K05
347866	TIE BAR SPARE WHEEL CLAMP	2H02
347866	PIVOT SPARE WHEEL MOUNTING	2H05
347866	PIVOT SPARE WHEEL MTG	2H12
347869	RUBBER PACKING SQUAB ASSEMBLY	2J09
347869	RUBBER PACKING SQUAB ASSEMBLY	2J13
347924	TRIM FINISHER	2F13
347924	TRIM FINISHER	2L12
347948	BRAKE WARNING LABEL	2L13
347955	RADIATOR GRILLE PANEL	2G05
348393	CHANNEL	2H16
348394	CHANNEL	2H16
348396	CHANNEL	2H16
348430	STUD	2J12
348430	WASHER-PLAIN	2J13
348430	STUD-SEAT STRAP RETAINING	2K02
348430	STUD-SEAT STRAP RETAINING	2K03
348430	STUD-SEAT STRAP	2K04

PART NUMBER	DESCRIPTION	REF.NO.
348430	STUD	2J09
348678	RUBBER SEAL	2H17
348747	STRIP RUBBER	1K03
348852	SIDE LOCKER LID	2G12
348855	CENTRE LOCKER LID	2G12
348859	DETACHABLE LID SEAT BASE	2G12
348869	GEAR BOX COVER	2G11
348874	REAR FLOOR	2H04
348882	COVER PLATE	2H04
348893	FLOOR PLATE	2G11
348894	FLOOR PLATE	2G11
349218	BRACKET	2J06
349218	BRACKET	2J07
349354	DASH TOP CASING	2J04
349362	RETAINING BRACKET	2J04
349364	DASH TOP CASING	2J04
349514	SQUAB ASSEMBLY REAR TRANSVERSE SEAT	2K04
349515	CUSHION	2K04
349515	SEAT CUSHION ASSEMBLY	2K06
349516	CUSHION INTERIOR-REAR SEAT	2K04
349516	INTERIOR FOR SEAT CUSHION	2K06
349529	SQUAB INTERIOR TRANSVERSE REAR SEAT	2K04
349764	DOOR TRIM	2J08
349765	DOOR TRIM	2J08
349772	MASK FOR WINDOW CATCH	2G15
349772	MASK-WINDOW CATCH TO SIDE SCREEN	2G17
349899	CLIP	2J07
349899	CLIP-TRIM RETAINING	2J08
349931	WASHER	2J09
349931	WASHER	2J11
349931	WASHER	2J13
349931	WASHER-PLASTIC	2K04
349931	WASHER PLAIN	2K05
349943	BRACKET	2J10
349943	BRACKET	2J11
349943	BRACKET	2J12
349943	BRACKET	2J09
349943	BRACKET	2J13
349967	CUSHION	2J12
349967	CUSHION	2J09
349996	ADJUSTABLE SEAT FRAME ASSY	2J13
349997	STOP	2J13
349998	EDGING STRIP	2J13
367030	JACK RETAINING BRACKET	2H02
367030	JACK RETAINING BRACKET	2H05

PART NUMBER	DESCRIPTION	REF.NO.
367030	JACK RETAINING BRACKET	2H07
367030	RETAINING BRACKET-JACK	2L11
367078	SPACER	2F15
371144	RETENTION RING	2H02
371144	RETENTION RING	2H05
371144	RETENTION RING	2H07
371144	RETENTION RING	2L11
392107	PAD	2K09
395014	FRT WING TOP/VALANCE ASSY-RH	2G07
395037	LOCK-REAR DOOR	2H18
395060	SUPPORT BRKT-INTERIOR MIRROR	2I03
395064	BOLT PLATE	1K04
395064	STUD PLATE-SEAT SUPPORT	2J09
395064	STUD PLATE-SEAT SUPPORT	2J10
395064	STUD PLATE-SEAT SUPPORT	2J11
395073	SUPPORT BRKT-INTERIOR MIRROR	2I03
395185	FLYSCREEN ASSEMBLY	2G09
395249	HARNESS BRACKET ASSEMBLY	2H08
395252	HARNESS BRACKET	2I15
395254	HARNESS TIE BAR RH	2I15
395255	HARNESS TIE BAR LH	2I15
395258	HARNESS BRACKET	2I15
395294	STRIKER-REAR DOOR	2H18
395404	FRONT PANEL ASSY BULKHEAD	2H04
395409	FRONT END PANEL ASSY REAR BODY	2H02
395413	TOE PANEL AND GUSSET BRACKET	2H08
395414	SHIM FOR HARNESS BRACKET	2H08
395414	PLATE-HARNESS ANCHORAGE	2I15
395459	FRONT APRON PANEL	2G05
395481	BUFFER CHECK STRAP	2G16
395507	PARCEL TRAY RH STG	2J03
395508	PARCEL TRAY LH STG	2J03
395516	CORNER CAPPING	2H17
395517	CORNER CAPPING	2H17
395529	FRONT DOOR RH	2G13
395530	FRONT DOOR LH	2G13
395533	FRONT DOOR RH	2G13
395534	FRONT DOOR LH	2G13
395538	CHECK STRAP ROD ASSEMBLY	2G16
395541	LOCK SEAL	2G15
395541	LOCK SEAL	2G18
395541	LOCK SEAL	2H18
395586	MOUNTING BRACKET RH	2J16
395587	MOUNTING BRACKET LH	2J16
395598	DOOR SEALING RUBBER RH	2G13

PART NUMBER	DESCRIPTION	REF. NO.
395599	DOOR SEALING RUBBER LH	2G13
395617	BLANKING PLATE	2G09
395652	LOCK RH-DOOR	2G18
395653	LOCK LH-DOOR	2G18
395658	BOLT PLATE	2I15
395670	DOOR SEALING RUBBER RH	2G13
395670	SEAL RH-LOWER REAR SIDE DOOR	2G17
395671	DOOR SEALING RUBBER LH	2G13
395671	SEAL LH-LOWER REAR SIDE DOOR	2G17
395672	SEALING RUBBER	2G14
395673	SEALING RUBBER	2H17
395674	SEALING RUBBER FOR DOORS	2G17
395674	SEAL-SIDE PANEL FRT AND RR	2H15
395674	SEAL RH-REAR DOOR SIDE	2H18
395699	PANEL-FLOOR REAR BODY	2H04
395702	REAR BODYSIDE PANEL RH	2H04
395703	REAR BODYSIDE PANEL LH	2H04
395711	COVER PLATE-RR FLOOR FRONT	2H04
395712	COVER PLATE-RR FLOOR REAR	2H04
395719	BODYSIDE ASSEMBLY RH	2H04
395720	BODYSIDE ASSEMBLY LH	2H04
395802	FRONT PLATE UPPER CRASH RAIL	2G09
395803	FRONT PLATE UPPER CRASH RAIL	2G09
395860	GRAB RAIL-STRAIGHT	2K04
395871	DEMISTER OUTLET	2J02
396005	NUT PLATE ASSEMBLY	2H08
396113	SEALING RUBBER HARD TOP	2H18
396116	INSTRUCTION LABEL	2G05
396124	HORN PROTECTOR PLATE	2G05
396139	SEALING RUBBER DASH	2G09
396415	RETAINER-RH	2J04
396416	RETAINER-LH	2J04
396423	SLEEVE FOR GRAB RAIL-STRAIGHT	2K04
396540	COVER ASSEMBLY SEAT BASE	2K03
396540	COVER ASSEMBLY SEAT BASE	2K04
396541	TRIM RETAINER OUTER	2K03
396542	TRIM RETAINER CENTRE	2K03
396542	TRIM RETAINER CENTRE	2K04
396606	TRIM-RH-CANT RAIL	2J06
396607	TRIM-LH-CANT RAIL	2J06
396696	PAD	2K07
396697	PAD FOR REAR SEAT BACKREST	2K08
396698	REAR SEAT BACKREST ASSEMBLY	2K08
396739	REAR SEAT BACKREST	2K07
396828	SIDE LIGHT CASING RH	2J07

PART NUMBER	DESCRIPTION	REF.NO.
396828	CASING RH-SIDE LIGHT	2J08
396829	SIDE LIGHT CASING LH	2J07
396829	CASING LH-SIDE LIGHT	2J08
396842	SIDE RAIL FOR HEAD LINING	2J06
396842	SIDE RAIL FOR HEAD LINING	2J06
396843	RETAINER ROOF TRIM AT VENTILATORS	2H17
396888	REAR HEAD LINING	2J06
396895	FRONT PORTION ROOF TRIM	2J06
396895	FRONT PORTION ROOF TRIM	2J07
396899	CANOPY TRIM PANEL	2J06
396899	CANOPY TRIM PANEL	2J07
396906	HEADCLOTH	2J07
396916	CENTRE SEAT COMPLETE ASSY	2K02
396920	CENTRE SEAT SQUAB INTERIOR	2K02
396922	CENTRE SEAT SQUAB TRIM BOARD	2K02
396922	CENTRE SEAT SQUAB TRIM BOARD	2K03
396933	CENTRE SEAT CUSHION INTERIOR	2K03
396937	BRACKET FOR STARTING HANDLE	2K03
396937	BRACKET FOR STARTING HANDLE	2K04
396986	HEADCLOTH	2J07
399041	BRACKET-VACUUM VALVE	1I13
399042	BRACKET-VACUUM VALVE	1I13
500201	FILLER CAP	1G04
500257	ACCELERATOR PEDAL	1007
500257	PEDAL-ACCELERATOR	1009
500257	PEDAL-ACCELERATOR	1011
500289	INTERMEDIATE EX PIPE	2C04
500290	SILENCER AND TAILPIPE 109 4 CYL	2C08
500419	FILTER GAUZE	1N06
500432	ELBOW	1002
500432	PIPE-OUTLET-FUEL TANK	1004
500446	DISTANCE TUBE	1002
500446	DISTANCE PIECE-FUEL TANK MOUNTING	1003
500446	DISTANCE PIECE-FUEL TANK MTG	1005
500446	TUBE-DISTANCE-FUEL TANK MOUNTING	1006
500447	MOUNTING RUBBER	1002
500447	MOUNTING-RUBBER-FUEL TANK	1003
500447	MOUNTING RUBBER-FUEL TANK	1005
500447	RUBBER-FUEL TANK MOUNTING	1006
500588	PACKING WASHER	1002
500588	PACKING WASHER-FUEL TANK MOUNTING	1003
500588	PACKING WASHER-FUEL TANK	1005
500588	WASHER-PACKING-FUEL TANK MOUNTING	1006
500609	SPRING	1D07
500710	JOINT WASHER	1N14

PART NUMBER	DESCRIPTION	REF.NO.
500710	JOINT WASHER	1N15
500710	JOINT WASHER	1N16
500710	GASKET-FUEL FILLER PIPE	1N17
500746	WASHER	1J16
500818	FUEL TANK ELBOW	1002
500978	JOINT WASHER SLEEVE TO AXLE	1J12
500978	GASKET SHAFT	1J13
501070	DISTANCE PIECE	1002
501070	PACKING WASHER-FUEL TANK MOUNTING	1003
501070	PACKING WASHER-FUEL TANK	1005
501070	DISTANCE PIECE-FUEL TANK MOUNTING	1006
501070	DISTANCE PIECE	2H16
501070	DISTANCE PIECE	2I02
501389	SCREW-ROAD SPRING	1J17
501390	MAIN LEAF	1J17
501391	2ND LEAF	1J17
501501	WASHER	1H04
501593	DOWEL	1C02
501593	DOWEL	1E02
502029	GUDGEON PIN	1E03
502116	DOWEL	1G02
502116	DOWEL	1G03
502202	HINGE	1H11
502205	BRACKET	1H11
502266	THRUST PLATE	1D06
502473	TAPPET GUIDE	1C06
502473	GUIDE-TAPPET	1E06
502482	DISTANCE PIECE	1H04
502687	SPECIAL SCREW FIXING CHOKE BUTTERFLY	1M02
502898	SPECIAL WASHER	1008
502899	SPACER FOR SPINDLE	1008
502900	SPINDLE BELL CRANK	1008
502904	VALVE SPRING	1D07
502951	FUEL INSTRUCTION PLATE	2H02
502951	BADGE-DIESEL FUEL	2H05
503307	CLAMP	2C03
503309	SHIELD	2C03
503352	BULB 12 ϕ V PEANUT TYPE/BAYONET TYPE	2F08
503352	BULB	2F13
503424	GREASE GUN	2L11
503456	INTERMEDIATE EXHAUST PIPE	2C05
503665	STARTING DOG	1C03
503665	STARTING DOG	1E03
503805	SPRING FOR SYNCROMESH BALL	1H04
503805	SPRING	1H06

PART NUMBER	DESCRIPTION	REF. NO.
503805	SPRING	1I06
503981	SPRING,PULL OFF	1L04
503981	SPRING	1L02
504006	SPRING WASHER	1C02
504006	WASHER	1E02
504211	DISTANCE PIECE FOR SHACKLE	1J16
504213	SHIM 0.003	1J16
504213	WASHER-SPACING	1J18
504214	SHIM 0.005	1J16
504214	WASHER-SPACING	1J18
504233	SEAL	1N14
504275	SHIM WASHER	1K04
504279	SHIM WASHER	1K04
504375	TIMING CHAIN	1C04
504606	TIE ROD	1D15
504607	SLEEVE	1D15
504620	RELAY LEVER	1O08
504655	CAP FUEL TANK FILLER	1N14
504655	CAP FUEL TANK FILLER	1N15
504655	CAP FUEL TANK FILLER	1N16
504656	TUBE	1N14
504656	TUBE	1N15
504656	TUBE	1N16
504657	TUBE	1N14
504657	TUBE	1N15
504657	TUBE	1N16
504673	JOINT WASHER	1N14
504995	VALVE-OIL RELIEF	1D05
504997	SPRING	1D05
505197	BULB LH STG	2F02
505198	BULB FOR HEAD LIGHT UNIT	2F02
505205	LUCAR CONNECTOR EARTHING	2F06
505205	EARTH BLADE	2J06
505205	EARTH BLADE	2J07
505244	JOINT WASHER	1N14
505244	JOINT WASHER	1N15
505244	JOINT WASHER	1N16
505244	GASKET-FUEL FILLER CAP	1N17
505597	SPACING WASHER	1D08
505790	SEAL	1L03
505855	FRONT EXHAUST PIPE	2C03
506047	STUD	1D11
506069	RUBBER WASHER	1C11
506069	RUBBER WASHER	1C12
506799	RING GEAR	1G02

PART NUMBER	DESCRIPTION	REF. NO.
506814	ADJ SCREW	1C06
506814	SCREW-TAPPET ADJUSTING	1E06
506816	SCREW	1D07
506817	SCREW	1D07
507025	SPECIAL SET BOLT	1C06
507025	BOLT-SPECIAL	1E06
507129	BULB	2F08
507447	PIN	1H11
507829	TAPPET ASSEMBLY	1C06
507829	TAPPET ASSEMBLY	1E06
508175	LOCKSTOP PLATE	1J05
508962	'D' WASHER	1013
508962	SPECIAL WASHER	1007
508962	WASHR-CURVED-ACCELERATOR PEDAL SHAFT	1009
508962	WASHER-SPECIAL	1011
509009	LEVER	1N10
509045	BOLT	1I10
509045	P BOLT(0.375" UNF X 1.125")	1J02
509045	P BOLT	1J03
509045	P BOLT	1J04
509045	P BOLT	1J14
509046	BOLT(0.375" UNF X 1.21875")	1J02
509120	HINGE PIN	2H16
509120	HINGE PIN	2I02
509218	DISTANCE TUBE FOR SHACKLE	1J18
509412	CLIP	1N13
509412	CLIP	1N13
509414	DOUBLE CLIP	1N11
509414	CLIP-FUEL PIPE	1N12
509414	CLIP-FUEL PIPE	1N13
509414	CLIP-FUEL PIPE	1N13
509415	CLIP	1N13
509415	CLIP	1N13
509463	PAD	1007
509463	PAD-RUBBER-ACCELERATOR PEDAL	1009
509463	PAD-RUBBER ACCELERATOR PEDAL	1011
509769	CHAIN FOR FILLER CAP	2D02
509885	BUSH	1D15
510170	WASHER	1N07
510170	WASHER-SHAKEPROOF	1N08
510823	BRAKE PIPE COMPLETE TO FRONT	1L09
511127	BUSH	1010
511680	SHAFT	1C04
511680	SHAFT-OIL PUMP	1E04
511833	GASKET	1N05

PART NUMBER	DESCRIPTION	REF. NO.
511834	VALVE GUIDE	1D11
512018	FAN BLADE	1C10
512206	VALVE ROCKER INLET RH	1C06
512207	VALVE ROCKER LH EXHAUST	1C06
512235	BANJO BOLT	1G05
512237	COVER	1H02
512287	NUT	1M06
512307	ADJUSTING SCREW CARBURETTER	1M06
512308	O RING FOR CARBURETTER	1M06
512311	O RING	1M06
512319	WASHER	1M06
512760	DUST COVER PLATE	1H10
512791	WASHER	1H10
512828	VALVE SEAT INSERT	1E11
513282	FAN DISC WASHER	2F10
513639	PUMP COVER	1C04
513639	BODY-OIL PUMP	1E04
513641	PUMP BODY	1C04
513641	BODY-OIL PUMP	1E04
513679	DRIVING DOG	2E02
513679	DOG-DISTRIBUTOR DRIVE	2E03
513682	SEALING RING	2L17
514224	TUBE	1E11
514578	RED BRAKE RUBBER GREASE-TUBE	2L07
515218	RIM FOR LIGHT UNIT	2F02
515291	SCREW	1C11
515291	SCREW	1C12
515291	BOLT	1D12
515291	BOLT-SPECIAL	1E12
515321	SPRING RETAINER	1C04
515325	PLUG-SPRING RETAINER	1C04
515365	ANCHOR PLATE	1L05
515366	EXPANDER UNIT ASSY	1L05
515405	ANCHOR PLATE RH	1L04
515405	ANCHOR PLATE	1L02
515406	ANCHOR PLATE LH	1L04
515406	ANCHOR PLATE	1L02
515466	DUST COVER	1L05
515467	LOCKING PLATE	1L05
515468	RETAINING SPRING	1L05
515470	PACKING PLATE	1L05
515505	DISTANCE PIECE	2C02
515505	DISTANCE PIECE	2E13
515506	BRACKET	2C02
515599	JOINT WASHER	1J02

PART NUMBER	DESCRIPTION	REF. NO.
515599	WASHER	1J03
515599	JOINT WASHER	1J12
515599	JOINT WASHER-DRAIN PLUG	1002
515599	JOINT WASHER-FUEL TANK DRAIN PLUG	1004
515845	BREATHER	1I04
515845	BREATHER	1J02
515845	BREATHER-AXLE	1J03
515845	BREATHER-AXLE	1J12
515848	SIDE COVER PLATE	1K02
515849	JOINT WASHER	1K02
515851	OUTPUT SHAFT	1H07
515853	THRUST WASHER LOW GEAR TO	1H08
515923	EXPANDER UNIT KIT	1L05
515923	REPAIR KIT FOR EXPANDER UNIT	2L07
515924	ADJUSTER UNIT KIT	1L05
515924	REPAIR KIT FOR ADJUSTER UNIT	2L07
515926	BRAKE ROD	1L05
515927	CLIP	1L05
516059	HOUSING	1C10
516059	HOUSING-THERMOSTAT	1E10
516133	ENGINE BRACKET RH	1C02
516133	MOUNTING ENGINE	1E02
516498	CYLINDER LINER	1D03
516885	GASKET LARGE	1D13
516946	SPRING	1M05
516951	SPRING-CARBURETTER SPINDLE	1M07
516951	SPRING	1M10
516951	THROTTLE RETURN SPRING	2L17
516951	SPRING	1M06
516962	CLIP FOR CHOKE SPINDLE LEVER	1M03
517469	FRONT EX PIPE	2C03
517588	SPRING	1J17
517589	SPRING	1J17
517632	FRONT EX PIPE	2C03
517684	CLIP	1N13
517684	CLIP	1N13
517689	PLUG	1N10
517690	NUT	1N10
517706	JOINT WASHER	1N10
517903	PIPE-ELBOW TO AIR CLEANER	1N02
517903	CONNECTION ELBOW TO AIR CLEANER	1N02
517907	SUPPORT BRACKET RESERVOIR TANK	1G04
517976	JOINT WASHER	1N10
517977	RUBBER MAT	2I02
518272	CORE PLUG	1C02

PART NUMBER	DESCRIPTION	REF. NO.
518272	CORE PLUG	1C11
518272	CORE PLUG	1D11
518272	CORE PLUG	1E02
518272	CORE PLUG	1E11
518318	THRUST WASHER	1H07
518653	GRUB SCREW	1M10
518848	DRIVE END BEARING KIT	2E10
518848	BEARING KIT-DRIVE END-	2E12
518848	BEARING KIT-ALTERNATOR-DRIVE END	2E14
520160	PARKING SWITCH FOR WIPER MOTOR	2F06
520464	BOLT KIT FOR STARTER MOTOR	2E07
520464	BOLT KIT	2E08
521328	THRUST WASHER	1H07
521452	CIRCLIP	1M12
521452	CIRCLIP FOR LEVER	2L12
521453	CIRCLIP	1M12
521522	SHIM FOR STEERING BOX 0.010	1K02
521583	BUSH	1D05
521633	SPECIAL NUT	1H04
521634	LOCK WASHER-MAINSHAFT GEAR	1H04
521636	WASHER FOR MAINSHAFT GEAR	1H04
521852	DISTANCE PIECE	1H04
521853	ROLLER BEARING	1H09
521855	BUSH FOR MAINSHAFT HOUSING	1H09
521856	RETAINING PLATE	1H09
521857	HOUSING ASSEMBLY REAR MAINSHAFT	1H09
521864	BUSH FOR LOW GEAR WHEEL	1H07
521868	HIGH GEAR WHEEL	1H07
522017	MAINSHAFT GEAR	1H04
522303	SELECTOR SHAFT	1H13
522308	SPRING SPACER TRANSFER SELECTOR	1H12
522318	HOUSING ASSEMBLY	1H09
522334	SELECTOR FORK	1H13
522567	DIFFERENTIAL CASING	1J08
522745	BUSH	1C04
522932	BUSH-THROTTLE SPINDLE	1F06
522940	WASHER	1N10
523139	CAMSHAFT	1D06
523181	BRACKET	1E06
523203	CUP-PLUG	1I10
523203	CLIP-RH ADAPTOR	1M11
523240	SPLIT SEAL HALVES	1C03
523240	RETAINER-OIL SEAL	1D04
523240	RETAINER-REAR MAIN BEARING	1E03
523638	TYRE PUMP	2L11

PART NUMBER	DESCRIPTION	REF. NO.
524492	CONNECTING ROD ASSY	1D04
524636	PACKING	1D03
524680	SHROUD	1E11
524765	CUP PLUG	1C11
524765	CUP PLUG	1E11
524846	ROCKER COVER TOP ASSY	1C11
524894	NUT PIPE TO FILTER OR BOWL	1N08
524894	NUT-FUEL PIPE	1N12
524959	PUMP CONNECTION	2L11
525124	INLET VALVE	1D07
525389	WASHER	1C06
525390	SCREW	1C06
525390	BOLT-SPECIAL	1E06
525428	PLUG	1C02
525428	CUP PLUG	1D03
525428	CUP PLUG	1E02
525497	CUP PLUG	1C02
525497	CUP PLUG	1C11
525497	CUP PLUG	1D03
525497	CUP PLUG	1D11
525497	CORE PLUG	1E02
525497	CUP PLUG	1E11
525500	SET BOLT (0.3125 UNF X 2.75")	1C06
525520	GASKET KIT	1E02
525520	ENGINE OVERHAUL GASKET KIT	2L07
525852	CRANKSHAFT ASSY 0.010 U/S	1C03
525853	CRANKSHAFT ASSY 0.020 U/S	1C03
525910	ROCKER	1D07
525911	ROCKER	1D07
526608	PAD FOR BUMP RUBBER FRONT	2G02
526994	TRACK ROD ONLY	1K06
527109	WATER OUTLET PIPE	1C10
527109	HOUSING-THERMOSTAT	1E10
527110	JOINT WASHER	1C10
527110	GASKET-THERMOSTAT HOUSING	1E10
527167	CRANKSHAFT ASSEMBLY STD	1C03
527167	CRANKSHAFT	1E03
527235	O RING FOR THERMOSTAT	1C10
527235	SEALING RING-THERMOSTAT	1E10
527269	PLUG	1C02
527269	CORE PLUG	1D03
527269	CORE PLUG	1E02
528004	GUDGEON PIN BUSH	1C03
528683	LOCK WASHER	1H05
528685	PLATE	1H05